

RS-232
MTS '96

GND
TxD
RxD
RTS
CTS

RS-232
Port 1

GND
TxD
RxD

RS-232
Port 2


Cable to badge.
Note red stripe.

Power connector location
for cable to power supply.

Jumper these to
enable Port 1 RTS

Jumper these to
enable Port 1 CTS

Power connector
for cable to badge.



Cable to RS-232 module.
Note red stripe.